




## Monitored Visonic Alarm Coded Reset



Display will read 'NOT READY MEMORY'

1. Press 'AWAY'  button, the alarm panel will say 'Please quote code to service company to retain reset'.
2. The display will scroll round from 'QUOTE CODE: \_\_\_\_\_' (a 5-digit code will be displayed), '(NEXT) ENTER CODE', and '(OK) FOR STATUS'. Do not press any button as the code will change if you exit out.
3. Ring Southern Monitoring Services on 0844 871 2223. The operator will require your Account Number and your Password. Quote code from alarm panel. A reset code will be issued to you.
4. Press the  button, the display will read 'RESET CODE: ■' (the black square will be flashing).
5. Type in reset code given to you by Southern Monitoring Services.  
Note: If the screen times out then you will have to start again as a different code is generated from the alarm panel.
6. If the wrong reset code is entered the alarm panel says 'sorry wrong code' and the display will read '!!! WRONG CODE' before returning to 'RESET CODE: ■' (the black square will be flashing). Enter correct reset code.
7. If entered correctly, the display will read 'READY and display the time'. The alarm system is now ready to use.